

Installation

Vor Öffnen Telefonstecker ziehen
Disconnect telephone line before opening
Débrancher ligne téléphonique avant d'ouvrir

1. 3 x beep

7.4



2.



Optional

3.



○ off
● wait
● alarm

flash

6 x beep: check

10



5 Program.

OFF ☐ ON
PROG

5.1

Handynummer eingeben
Entrer numéro du portable
Enter mobile number

OFF ☐ ON
PROG

6.4 Test

OFF ☐ ON
PROG

Eine Taste drücken
Appuyer une touche
Press any key

0 drücken
Appuyer 0
Press 0

OFF ☐ ON
PROG

6 Operation

OFF ☐ ON LOW ☐ HIGH
PROG MED

6.3

2Min.

3 x → HIGH
6 x → MED
8 x → LOW

0 drücken
Appuyer 0
Press 0

OFF ☐ ON
PROG