






















# Installation

		bébételEXTRA bébételMOBILE	COMBI	
<div>  <div> <div>1</div> <div>3 x beep</div> <div>7.7</div> </div> </div>  <div> <div>○ off</div> <div>● wait</div> <div>● alarm</div> </div> <div> <div>⚡ flash</div> <div>   </div> </div>	<div>2</div> 	 	<div>       </div> 	
		  <div>Not for bébéTEL CLASSIC</div>	  <div>6 x beep: check</div> <div>3a 3b 10</div> <div>www.bebetel.com/mobiles</div>	 
<div>  <div> <div>1. Vor dem Öffnen des Batteriefachs Telefonstecker 3a ziehen.</div> <div>1. Débrancher la ligne téléphonique avant d'ouvrir.</div> <div>1. Disconnect telephone line before opening.</div> </div> <div> <div>2. 3a und 3b nie gleichzeitig einstecken.</div> <div>2. Jamais brancher 3a et 3b en même temps.</div> <div>2. Never connect 3a together with 3b.</div> </div> </div>				

5



Program.

OFF

ON

PROG

5.1

Handynummer eingeben

Entrer numéro du portable

Enter mobile number

OFF

ON

PROG

6.4

Test

OFF

ON

PROG

1

2

3

4

5

6

7

8

9

\*



0

#

Eine Taste drücken

Appuyer une touche

Press any key

0 drücken

Appuyer 0

Press 0

OFF

ON

PROG

6

Operation

OFF

ON

LOW

HIGH

PROG


MED

6.3

2Min.

⌚

⌛



3 x



→ HIGH

6 x

→ MED

8 x

→ LOW

0 drücken

Appuyer 0

Press 0

OFF

ON

PROG